


## MX-xx-120 Shim Installation Instructions

Each shim kit contains enough shims for 1 axle (four 0.005" shims – part number 2803-L-3444, four 0.015" shims – part number 2803-M-3445 and four 0.025" shims – part number 2803-N-3446).

- 1. Measure the vertical endplay of the knuckle
- 2. Use the chart below to determine the quantity of each shim that needs to be installed.
- 3. Install shims between the housing and the steering arm/upper cap see diagram on reverse
- 4. Measure the vertical endplay of the knuckle and verify that it falls between 0.005 and 0.015 inches.

	Number of Shims to Install			
Initial Vertical Endplay (inches)	0.005" (2803-L-3444)	0.015" (2803-M-3445)	0.025" (2803-N-3446)	Final Vertical Endplay (inches)
0.000 - 0.015	-	-	-	0.000 - 0.015
0.010 - 0.020	1	-	-	0.005 – 0.015
0.015 - 0.025	2	-	-	0.005 – 0.015
0.020 - 0.030	-	1	-	0.005 - 0.015
0.025 - 0.035	1	1	-	0.005 - 0.015
0.030 - 0.040	-	-	1	0.005 – 0.015
0.035 - 0.045	1	ı	1	0.005 - 0.015
0.040 - 0.050	2	-	1	0.005 - 0.015
0.045 - 0.055	-	1	1	0.005 - 0.015
0.050 - 0.060	1	1	1	0.005 - 0.015
0.055 - 0.065	-	-	2	0.005 - 0.015
0.060 - 0.070	1	ı	2	0.005 - 0.015
0.065 - 0.075	2	ı	2	0.005 - 0.015
0.070 - 0.080	-	1	2	0.005 - 0.015
0.075 - 0.080	1	1	2	0.005 - 0.010
0.08	2	1	2	0.005
More Than 0.080	Recheck Measurement. If still greater than 0.080" contact customer service.			



## **ArvinMeritor**<sub>m</sub>

Commercial Vehicle Aftermarket

Meritor Heavy Vehicle Systems, LLC 7975 Dixie Highway Florence, KY 41042 USA 888-725-9355 www.meritorhvs.com www.xpresswayplus.com Information contained in this publication was in effect at the time the publication was approved for printing and is subject to change without notice or liability. ArvinMeritor reserves the right to revise the information presented or discontinue the production of parts at any time.

© 2006 ArvinMeritor, Inc.

Printed in U.S.A.

Issued 5/2006 TP-0690